



THIS LAYOUT IS INDICATIVE ONLY.  
CONSULT SPACIAL CONCEPTS FOR  
OBLIGATION FREE DESIGN HELP.

Number of Panels	Typical = Opening Width (from REAR of Cupboard) Divided by 1200 (round up)
Panel Width	Typical = Opening width divided by Number of Panels.
Panel Thickness (inc. hinges)	Typical = Glass Panel 60mm
Clearance Depth	$D = \text{Jamb} + \text{Number of Panels} \times \text{Thickness} + 50\text{mm} \text{ (safety)}$
Depth of Nibs	$N = D + \text{cupboard doors, jambs, flap \& hardware.}$
Clearance Width	$W = \text{Panel Width} + 2 \times 100\text{mm clearances.}$
Width of Flap	$F = \text{Panel thickness} + 40\text{mm clearance.}$